

Universal Serial Bus  
Communications Class  
Subclass Specification for  
Ethernet Emulation Model Devices

Revision 1.0

February 2, 2005

## Revision History

Rev	Date	Filename	Comments
0.6	8/25/03	CDC_IPUSB06.DOC	First Draft for internal CDC review
0.7	10/1/03	CDC_IPUSB07.DOC	Comments / Suggestions from 10-1-03 CDC DWG.
0.7a	12/1/03	CDC_IPUSB07.DOC	Comments / Suggestions from CDC reflector
0.7b	12/5/03	CDC_IPUSB07b.DOC	Comments / Suggestions from CDC members prior to meeting
.0.7c	12/6/03	CDC_IPUSB07c.DOC	Comments / Suggestions from 12-5-03 CDC DWG.
.08rc0	2/17/04	CDC_EEM08rc0.doc	Comments / Suggestions from 2-5-04 DWG an RR's.
.08rc1	2/26/04	CDC_EEM08rc1.doc	Move IP over EEM information to separate document.
.08rc2	4/7/04	CDC_EEM08rc2.doc	Comments and suggestions from 4-7-2004 group meeting.
.08rc3	4/7/04	CDC_EEM08rc3.doc	Comments and suggestions from 4-7-2004 dinner meeting.
.08rc4	4/9/04	CDC_EEM08rc4.doc	Comments and suggestions from 4-7-04 DWG.
.08rc5	5/26/04	CDC_EEM08rc5.doc	Comments and suggestions from 5-26-04 working session.
.08rc6	5/26/04	CDC_EEM08rc6.doc	Updates from meeting feedback.
.08rc7	6/29/04	CDC_EEM08rc7.doc	Final updates for .8 approval
.08	8/5/04	CDC_EEM08.doc	.8 submit
.08a	10/6/04	CDC_EEM08a.doc	Define EEM Command packet. Add echo and suspend.
.09rc1	12/1/04	CDC_EEM09rc1.doc	Accept changes to remove change bars and prepare for public release.
.09	12/8/04	CDC_EEM09.doc	Change title to reflect numerical promotion.
1.0	2/2/05	CDC_EEM10.doc	Title change and removal of obsolete references.

Please send comments or questions to : [cde@usb.org](mailto:cde@usb.org)

**Copyright © 2004, 2005 USB Implementers Forum, Inc. (USB-IF).**

**All rights reserved.**

#### INTELLECTUAL PROPERTY DISCLAIMER

THIS SPECIFICATION IS PROVIDED "AS IS" WITH NO WARRANTIES WHATSOEVER INCLUDING ANY WARRANTY OF MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE, OR ANY WARRANTY OTHERWISE ARISING OUT OF ANY PROPOSAL, SPECIFICATION, OR SAMPLE.

A LICENSE IS HEREBY GRANTED TO REPRODUCE AND DISTRIBUTE THIS SPECIFICATION FOR INTERNAL USE ONLY. NO OTHER LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE, TO ANY OTHER INTELLECTUAL PROPERTY RIGHTS IS GRANTED OR INTENDED HEREBY.

AUTHORS OF THIS SPECIFICATION DISCLAIM ALL LIABILITY, INCLUDING LIABILITY FOR INFRINGEMENT OF PROPRIETARY RIGHTS, RELATING TO IMPLEMENTATION OF INFORMATION IN THIS SPECIFICATION. AUTHORS OF THIS SPECIFICATION ALSO DO NOT WARRANT OR REPRESENT THAT SUCH IMPLEMENTATION(S) WILL NOT INFRINGE SUCH RIGHTS.

All product names are trademarks, registered trademarks, or service marks of their respective owners.

## Contributors

Russ Winsper	Apple Computer
Michael Montgomery	Axalto
Bill Russell	Canon
Robbie Harris	Hewlett Packard
Smith Kennedy	Hewlett Packard
John Van Boxtel	Hewlett Packard
Joel Silverman	Kawasaki LSI
Ariel Sobelman	M-Systems
Joe Decuir	MCCI
Terry Moore	MCCI
Paul Berg	MCCI
Randy Aull	Microsoft Corporation
Fred Bhesania	Microsoft Corporation
Igor Kostic	Microsoft Corporation
Brian King	Microsoft Corporation
Aditya Dube	Microsoft Corporation
Jim Blackson	YE Data

## Table of Contents

<b>1</b>	<b>Introduction.....</b>	<b>7</b>
1.1	Purpose .....	7
1.2	Scope.....	7
1.3	Related Documents .....	9
1.4	Terms and Abbreviation .....	9
<b>2</b>	<b>Management Overview.....</b>	<b>12</b>
2.1	What is Ethernet Emulation Model (EEM)? .....	12
<b>3</b>	<b>Assumptions and Constraints .....</b>	<b>13</b>
3.1	USB Specification.....	13
3.2	Class-Specific Codes for EEM Devices.....	13
3.2.1	Communication Class Code .....	13
3.2.2	Communication Class Subclass Codes.....	13
3.2.3	Communication Class Protocol Codes.....	13
3.3	Device Framework.....	14
3.3.1.1	Function Addressing .....	14
<b>4</b>	<b>Functional Overview .....</b>	<b>15</b>
4.1	Function Models .....	15
4.2	Endpoint Requirements .....	15
<b>5</b>	<b>Functional Characteristics .....</b>	<b>16</b>
5.1	EEM Packet.....	16
5.1.1	EEM Packet Format.....	16
5.1.2	EEM Packet Types .....	17
5.1.2.1	EEM Data Packet.....	17
5.1.2.2	EEM Command Packet.....	18
5.1.2.2.1	Echo .....	19
5.1.2.2.2	Echo Response.....	19
5.1.2.2.3	SuspendHint.....	20
5.1.2.2.4	ResponseHint.....	20
5.1.2.2.5	ResponseCompleteHint .....	20
5.1.2.2.6	Tickle Command .....	21
5.1.2.3	Special Packets.....	21
5.1.2.3.1	Zero Length EEM (ZLE) .....	21
5.1.3	EEM Packet Handling.....	22
5.1.3.1	Receiving Packets.....	22
5.1.3.1.1	Receive Command Packet.....	23
5.1.3.1.2	Receive Data Packet.....	23
5.1.3.2	Sending Packets .....	24
5.2	Transfers.....	25
5.3	Wakeup Support.....	26
<b>6</b>	<b>Device Requests.....</b>	<b>27</b>
<b>Appendix A: EEM Installation Example .....</b>	<b>28</b>	
A.1 Installation Overview.....	28	
A.2 USB Installation Overview .....	29	

<b>Appendix B: Example Driver Architecture .....</b>	<b>30</b>
<b>Appendix C: Network MAC Configuration Example.....</b>	<b>32</b>
<b>Appendix D: EEM Frequently Asked Questions .....</b>	<b>33</b>
What are the benefits of EEM? .....	33
Why not use Ethernet?.....	33
Does this replace the need for USB device classes? .....	33
How to I get a MAC address for my company? .....	33
<b>Appendix E: EEM Packet handling examples .....</b>	<b>34</b>
E.1 Sending small EEM Packets .....	34
E.2 Sending large EEM packets (> bMaxpacket) .....	36
E.3 Bundling EEM Packets .....	38
<b>Appendix F: EEM Hardware Architecture Walkthrough.....</b>	<b>40</b>
<b>Appendix G: Ethernet Bridging .....</b>	<b>42</b>

## 1 Introduction

### 1.1 Purpose

This document specifies the behavior of Ethernet Emulation Model (EEM) Devices. The document was designed with multifunction devices in mind, but is limited in no way to this implementation alone.

### 1.2 Scope

This document specifies new device subclasses intended for use with Communication devices, based on the Universal Serial Bus Class Definitions for Communication Devices specification [USBCDC].

The intention of this specification is that all material presented here be upwards-compatible extensions of the [USBCDC] specification. New numeric codes are defined for subclass codes, protocol codes, management elements, and notification elements.

In some cases material from [USBCDC] is repeated for clarity. In such cases, [USBCDC] shall be treated as the controlling document.

In this specification, the word ‘shall’ or ‘must’ is used for mandatory requirements, the word ‘should’ is used to express recommendations and the word ‘may’ is used for options.



### 1.3 Related Documents

USB2.0	<i>Universal Serial Bus Specification</i> , revision 2.0 (also referred to as the <i>USB Specification</i> ). This specification is available on the World Wide Web site <a href="http://www.usb.org">http://www.usb.org</a> .
USBCCS1.0	Universal Serial Bus Common Class Specification, revision 1.0. This specification is available on the World Wide Web site <a href="http://www.usb.org">http://www.usb.org</a>
USBCDC1.1	<i>Universal Serial Bus Class Definitions for Communication Devices</i> , Version 1.1. This specification is available on the World Wide Web site <a href="http://www.usb.org">http://www.usb.org</a> .
USBMASS1.1	<i>Universal Serial Bus Mass Storage Class Specification Overview</i> , Release 1.1. This specification is available on the World Wide Web site <a href="http://www.usb.org">http://www.usb.org</a> .
USBPRINT1.1	<i>Universal Serial Bus Device ClassDefinition for Printing Devices</i> , Release 1.1. This specification is available on the World Wide Web site <a href="http://www.usb.org">http://www.usb.org</a> .
USB_STIL_IMG1.0	<i>Universal Serial Bus Still Image Capture Device Definition</i> , Revision 1.0. This specification is available on the World Wide Web site <a href="http://www.usb.org">http://www.usb.org</a> .
<i>IEEE 802.3-2002 (ISO/IEC 8802-3)</i>	<i>Carrier sense access with multiple collision detection</i>

### 1.4 Terms and Abbreviation

Term	Description
Anycast	Communication between a single sender and the nearest of several receivers in a group.
ARP	Address Resolution Protocol associates an IP address to a hardware address called a Media Access Control (MAC) address.
Address Resolution Protocol (ARP)	An ARP probe is an ARP request with the device hardware address used as the sender's hardware address and the

probe.	sender's IP address set to 0s.
Descriptor	Data structure used to describe a USB device capability or characteristic
Device	A logical or physical entity that performs a function. The actual entity described depends on the context of the reference. At the lowest level, device may refer to a single hardware component, as in a memory device. At a higher level, it may refer to a collection of hardware components that perform a particular function, such as a USB interface device. At an even higher level, device may refer to the function performed by an entity attached to the USB; for example, a data/FAX modem device. Devices may be physical, electrical, addressable, and logical. When used as a non-specific reference, a USB device is either a hub or a function.
DHCP	Dynamic Host Configuration Protocol is a protocol for organizing and simplifying the administration of IP configuration for computers in a network.
ECM	Ethernet Control Model. as defined in CDC Device Class specification.
EEM	Ethernet Emulation Model
EEM Transfer	USB Transfer containing one or more EEM packets
ENA	External Network Adapter
Ethernet	IEEE 802.3
Firewall	A filtering module located on a gateway machine that examines all incoming and outgoing traffic to determine if it may be routed to its destination.
Function	Device capabilities exposed over the USB cable.
IP address	An IP address is a unique number, which identifies a computer in an IP network.
MAC address	Media Access Control address is more specific than an IP address and cannot be changed because it is specific to each network hardware device.
Multicast	Communication between a single sender and multiple receivers on a network.
Multifunction device	A device of peripheral that exposes one or more functions or services to an end user. Exposed services can but do have to

	be exposed as USB functions.
Port	A port is a 16-bit number (the allowed range being 1 through 65535) used by the TCP and UDP protocols at the transport layer. Ports are used to address applications (services) that run on a computer.
Service	Device capabilities exposed over an EEM function.
Socket	A socket represents a single connection between two network applications.
Unicast	Communication between a single sender and a single receiver over a network
ZLE	Zero Length EEM Packet. Refer to 5.1.2.3.1.
ZLP	Zero Length Packet Refer to [USB2.0] Section 8.5.3.2.

## 2 Management Overview

Ethernet Emulation Model (EEM) is a specification for inexpensive and efficient transport of Ethernet frame across the USB bus. EEM prepends the Ethernet frame (Ethernet header, payload, and CRC) with a small header to enable concatenation of frames within a USB transfer. EEM enables the leveraging of the extensive infrastructure that is implemented above Ethernet in USB hosts. How the corresponding network infrastructure layered above Ethernet is implemented within the device is beyond the scope of this specification. Examples of this include but are not limited to transports IPv4 and IPv6, discovery protocols such as UPnP and Rendezvous, and web applications.

EEM's endpoint requirements consist solely of a bulk pair (In and Out).

Unlike CDC ECM, EEM does not extend an interface across the USB bus but instead considers the USB bus to be a vehicle for moving Ethernet packets.

EEM enables leveraging the network stack over USB and Ethernet interfaces.

Prior to EEM, specialized services needed to either create a device class within the USB DWG or a Vendor specific Device. Utilizing EEM allows existing upper layer networking protocols to discover and use new services.

### 2.1 What is Ethernet Emulation Model (EEM)?

EEM is the encapsulation of Ethernet frames for transport across the USB bus.




Figure 1 Depiction of an EEM device and host

### 3 Assumptions and Constraints

This section describes assumptions and constraints related to compliance.

#### 3.1 USB Specification

#### 3.2 Class-Specific Codes for EEM Devices

This section lists the codes for the Communication Device Class, Communication Interface Class and Data Interface Class, including subclasses and protocols. These values are used in the *DeviceClass*, *bInterfaceClass*, *bInterfaceSubClass*, and *bInterfaceProtocol* fields of the standard device descriptors as defined in chapter 9 of the *USB Specification*.

##### 3.2.1 Communication Class Code

The following table defines the Communications Device Class code:

**Table 1 Communication Device Class Code**

Code	Class
02h	Communication Device Class

##### 3.2.2 Communication Class Subclass Codes

The following table defines the Communication Subclass code:

**Table 2 Class Subclass Code**

Code	Subclass
0Ch	Communication Device Subclass / EEM

##### 3.2.3 Communication Class Protocol Codes

The following table defines the EEM Protocol code:

**Table 3 Class Protocol Code**

Code	Protocol
07h	EEM

If a Communication Class interface appears with multiple alternate settings, all alternate settings for that interface shall have the same bInterfaceClass, bInterfaceSubclass and bInterfaceProtocol codes.

### 3.3 Device Framework

#### 3.3.1.1 Function Addressing

Each EEM function must have a unique MAC address. The registration process and fees for obtaining MAC addresses is covered on the IEEE website (<http://standards.ieee.org/faqs/OUI.html>).

## 4 Functional Overview

### 4.1 Function Models

[USB2.0] defines “function” as a “USB device that provides a capability to the host, such as an ISDN connection, a digital microphone, or speakers”. Further, in section 5.2.3, it says “Multiple functions may be packaged into what appears to be a single physical device.... A device that has multiple interfaces controlled independently of each other is referred to as a composite device.” We therefore adopt the term “function” to describe a set of one or more interfaces which taken together provide a capability to the host.

This document defines the following new kinds of functions:


- Ethernet Emulation Model (EEM)

### 4.2 Endpoint Requirements

The EEM Device Class uses the standard Endpoint descriptor, as defined in chapter 9 of the *USB Specification*.

The only endpoint requirement imposed by this specification is a single pair of bulk-in/bulk-out endpoints.

A pair of bulk endpoints, an IN and an OUT, would be used to send and receive the frames (as shown in Figure 2 Endpoint Requirements).



**Figure 2 Endpoint Requirements**

## 5 Functional Characteristics

### 5.1 EEM Packet


The payload of the USB packet contains any combination of a single EEM Packet (refer to Figure 3 USB Packet with single EEM payload), two or more EEM Packets (refer to Figure 4 USB Packet with EEM bundle) or a split EEM packet (refer to Figure 5 USB Packet with EEM bundle and split EEM).




**Figure 3 USB Packet with single EEM payload**



**Figure 4 USB Packet with EEM bundle**



**Figure 5 USB Packet with EEM bundle and split EEM**



**Figure 6 USB Packet with split EEM**

EEM packets can be split across USB packets but shall not be split across USB transfers.

#### 5.1.1 EEM Packet Format

The packet format defines an EEM packet. For information regarding USB packets refer to [USB2.0] specification. Details packets formats can be found in section 8.4 of the [USB2.0] specification.

Transfer Type	Packet Format
Bulk Transfer	Refer to section 5.8 of [USB2.0] specification


**Table 4 USB Packet Format Reference**

An EEM data packet, contains a header prepended to an Ethernet Frame.

**Figure 7 EEM Packet**

### 5.1.2 EEM Packet Types

The EEM Packet header contains a bmType field to denote whether EEM packet is an EEM Data packet or EEM Command Packet.

**Figure 8 EEM Packet Header Example****Table 5 Values for bmType**

bmType	Purpose
0	Default. EEM data payload
1	EEM Command

#### 5.1.2.1 EEM Data Packet

An EEM Data packet is used to transport Ethernet frames over a USB cable. The EEM Data Packet header contains a bmCRC field to denote whether the CRC field in the Ethernet Frame contains a calculated CRC or a sentinel value of 0xdeadbeef followed by the length of the Ethernet Frame.




Figure 9 EEM Data Packet Header Pictorial

Table 6 EEM Data Packet Format

Offset	Field	Size	Value	Description
0	bmEEMDataHdr	2	Bit mask	D15: bmType. Set to 0 D14: bmCRC D13-D0:Length of Ethernet Frame

Table 7 Values for bmCRC

bmCRC value	Purpose
0	Ethernet Frame CRC is set to 0xdeadbeef
1	Ethernet Frame CRC has been calculated

### 5.1.2.2 EEM Command Packet

An EEM Command packet provides local USB link management. The EEM command header and EEM command payload shall not be transmitted beyond USB driver layers.




Figure 10 EEM Command Packet Header Pictorial

Table 8 Values for bmReserved

bmReserved	Purpose
0	Default

**Table 9 Values for bmEEMCmd**

<b>bmEEMCmd</b>	<b>Purpose</b>
0	Echo
1	Echo response
2	SuspendHint
3	ResponseHint
4	ResponseCompleteHint
5	Tickle
6-7	Reserved for future use.

#### 5.1.2.2.1 Echo

An Echo command is used for USB link validation. EEM Echo commands can be initiated by either host or device..

Upon receipt of an Echo command, an Echo Response command packet with identical command payload is sent.

**Table 10 EEM Packet format for Echo Command**

<b>Offset</b>	<b>Field</b>	<b>Size</b>	<b>Value</b>	<b>Description</b>
0	bmEEMCommandHdr	2	Bit mask	D15: 1 D14: 0 D13-D11: 000b D10-D0: EEM Echo Length
1	EchoData	Length	Variable	Command Payload (Data to be echoed)

#### 5.1.2.2.2 Echo Response

A single Echo Response command shall be sent in response to an Echo command (see 5.1.2.2.1).

**Table 11 EEM Packet format for Echo Response Command**

Offset	Field	Size	Value	Description
0	bmEEMCommandHdr	2	Bit mask	D15: 1 D14: 0 D13-D11: 001b D10-D0: EEM Echo Length
1	EchoReturn	Length	Variable	Command Payload (Data to be echoed)

#### 5.1.2.2.3 SuspendHint

A SuspendHint is initiated by the peripheral to inform the host the peripheral has entered a state where it is safe to suspend. The host is not required to make use of this information.

**Table 12 EEM Packet format for SuspendHint Command**

Offset	Field	Size	Value	Description
0	bmEEMCommandHdr	2	Bit mask	D15: 1 D14: 0 D13-D11: 010b D10-D0: 0000 0000 000b

#### 5.1.2.2.4 ResponseHint

A ResponseHint is initiated from the peripheral to inform the host of a suggested response time interval in which the host may suspend polling of the device. After receiving this command, the host may suspend polling for a time interval not to exceed the specified response time interval. The host may choose to ignore this hint.

**Table 13 EEM Packet format for ResponseHint Command**

Offset	Field	Size	Value	Description
0	bmEEMCommandHdr	2	Bit mask	D15: 1 D14: 0 D13-D11: 011b D10-D0: Suggested Response Interval in milliseconds

#### 5.1.2.2.5 ResponseCompleteHint

A ResponseCompleteHint command is initiated from the peripheral to inform the host the peripheral has no further information to transmit to the host at this time. The device shall not have any further information to transmit to the

host until one or more of the following conditions have been met:

- Host transmits data to the device.
- Timeout of bmEEMCmdParam **seconds** has expired.

After receiving this command, the host may suspend polling until either the host transmits data to the device, or until a time interval not to exceed the specified timeout has elapsed. The host may choose to ignore this hint.

If the timeout expires before the host sends data, the host may send a Tickle command to the device. However, since the host may choose to ignore this hint, the device cannot depend upon a Tickle command being sent upon timeout.

**Table 14 EEM Packet format for ResponseCompleteHint Command**

Offset	Field	Size	Value	Description
0	bmEEMCommandHdr	2	Bit mask	D15: 1 D14: 0) D13-D11: 100b D10-D0:Timeout in seconds

#### 5.1.2.2.6 Tickle Command


A Tickle command may be initiated by the host to signal a timeout from a ResponseCompleteHint command. Because the host may choose to ignore the ResponseCompleteHint command, the device cannot depend upon a Tickle command being sent upon timeout.

**Table 15 EEM Packet format for Tickle Command**

Offset	Field	Size	Value	Description
0	bmEEMCommandHdr	2	Bit mask	D15: 1 D14: 0 D13-D11: 101b D10-D0:0000 0000 000b

#### 5.1.2.3 Special Packets

##### 5.1.2.3.1 Zero Length EEM (ZLE)



**Figure 11 Zero Length EEM (ZLE)**

### 5.1.3 EEM Packet Handling

EEM packet formats and handling of those packets is identical for host to device or device to host transactions.

#### 5.1.3.1 Receiving Packets

Figure 12 Example EEM Packet Receive Flowchart is an example algorithm for receiving USB transfers containing EEM packets.




Figure 12 Example EEM Packet Receive Flowchart

#### 5.1.3.1.1 Receive Command Packet




Figure 13 Example EEM Command Packet Receive Flowchart

#### 5.1.3.1.2 Receive Data Packet




Figure 14 Example EEM Data Packet Receive Flowchart

### 5.1.3.2 Sending Packets




Figure 15 Example EEM Data Packet Send Flowchart

## 5.2 Transfers

The transfer format defines an EEM transfer. For information regarding USB transfers refer to [USB2.0] specification. Details regarding USB transfers can be found in section 5.4 of the [USB2.0] specification.

As per [USB2.0] specification, section 5.8.3, the last packet of the USB transfer shall be a short packet, to mark the end of the transfer. If the buffered data would not result in the last packet being a short packet, i.e. the data length is an exact multiple of bMaxpacket, an additional packet shall be added to insure that the last packet is a short packet. This additional packet can either be a ZLP (zero length packet) or ZLE (refer to 5.1.2.3.1) packet.

### 5.3 Wakeup Support

If the device indicates that it supports wakeup, and the host has set the remote wakeup feature in this session, and all other (USB 2.0 specification standard) conditions for generating remote wakeup signaling have been met, and the EEM function has data to send to the host now, THEN the device shall generate a remote wake signal.

## 6 Device Requests

No additional class-level requests are defined by this specification. Existing CDC or WMC class requests are not supported unless otherwise called out.

## Appendix A: EEM Installation Example

### A.1 Installation Overview

Refer to Figure 16 Installation Example (Big Picture) as a guide for the installation algorithm listed below.

Step 0: Device is turned on and/ or plugged in.

Step 1: USB installation occurs. Refer to Appendix A.2 for more details.

Step 2: Pending read from EEM device class to initiate network addressing.

Step 3: Network addressing occurs. Network addressing (or equivalent) would be covered in the appropriate Ethernet compatible Network layer documentation.

Step 4: Service Installation begins. Service discovery details will be found in Ethernet compatible service discovery documentation.

Step 5: EEM function and child services are ready for use.





Figure 16 Installation Example (Big Picture)

## A.2 USB Installation Overview




**Figure 17 USB Installation**

## Appendix B: Example Driver Architecture


Implementers are free to use whatever driver structure best suit their technical and commercial goals. However, for readers unfamiliar with the details of using multifunction (multiple services) devices, this section shows an example driver architecture that can be used to integrate the functionality of an example EEM peripheral into an operating system. This section is informative, not normative.

For the purposes of discussion, we assume a relatively complicated device, containing the following services:

- Web server
- Storage
- Print
- Fax
- Scan


**Figure 18 Example Driver Architecture**

## Appendix C: Network MAC Configuration Example



**Figure 19 One or more EEM's per Host NICs**

Figure 19 One or more EEM's per Host NICs shows a configuration where one or more devices are connected to a single NIC driver in the host PC. In this example, MAC1 is derived from the host software implementation. MAC's two and three come from their perspective peripherals.



**Figure 20 MAC Example**

Figure 20 MAC Example shows a configuration where each device connects to a single NIC driver in the host PC. In this example, MAC's one and two come from their perspective peripherals.

## Appendix D: EEM Frequently Asked Questions

### What are the benefits of EEM?

EEM enables a network interface over USB. Software can be leveraged between network and USB connected peripherals.

### Why not use Ethernet?

There are many reasons to use USB plug instead of an Ethernet plug. This is a vendor specific model. Common reasons are listed below. The list is not conclusive, but can serve as a reference to some of the many possible reasons.

1. Connector size

USB based peripherals can choose from a number of standard form factors.

2. Electrical

The USB cable provides power. Ethernet does not.

3. Install base

The peripheral may wish to have enable EEM to a market segment that has a USB connector.

### Does this replace the need for USB device classes?

No. The goal of EEM is to provide an economical network interface over USB. Using services over a network connection is a natural extension of this technology. The benefits of enumerating services over TCP/IP over EEM or a USB device class need to be weighed by the hardware vendor.

### How to I get a MAC address for my company?

The registration process and fees are covered on the IEEE website (<http://standards.ieee.org/faqs/OUI.html>).

## Appendix E: EEM Packet handling examples

### E.1 Sending small EEM Packets





Figure 21 Sending EEM packets  $<$  `bMaxPacket`

- Step 1: Host based Ethernet driver sends Ethernet frame to USB driver.
- Step 2: Host based USB driver accepts Ethernet frame from upper driver. Host based USB driver creates EEM packets by prepending header to Ethernet Frame.
- Step 3: Host based USB drivers packs EEM Packet into USB Packet. Note: This example assumes `sizeof(enet_frame) < bMaxPacket`.

- Step 4: Host based USB driver sends USB Packet (with payload) across the wire to the device.
- Step 5: Device based USB driver accepts the USB Packet.
- Step 6: Device based USB driver unpacks the EEM packet to get header and Ethernet Frame. Ethernet Frame is sent to device based Ethernet driver.
- Step 7: Device based Ethernet driver accepts Ethernet frame.

## E.2 Sending large EEM packets (> bMaxpacket)




**Figure 22** Sending enet frames > bMaxPacket

- Step 1: Host based Ethernet driver sends Ethernet frame to USB driver.

- Step 2: Host based USB driver accepts Ethernet frame from upper driver. . Host based USB driver creates EEM packets by prepending header to Ethernet Frame.
- Step 3: Host based USB drivers splits EEM packet to bMaxpacket sized chunks.
- Step 4: Each chunk is packed into a USB Packet.
- Step 5: Host based USB driver sends USB Packet(s) (with payload) across the wire to the device. Device based USB driver accepts the USB Packet.
- Step 6: Device based USB driver unpacks the chunks.
- Step 7: EEM packet is reassembled. .Ethernet Frame is extracted from EEM packet. Ethernet frame is sent to device based Ethernet driver.
- Step 8: Device based Ethernet driver accepts Ethernet frame.

### E.3 Bundling EEM Packets




**Figure 23 Bundling Ethernet Frames**

- Step 1: Host based Ethernet driver sends one or more Ethernet frame to USB driver.

- Step 2: Host based USB driver accepts Ethernet frame(s) from upper driver. Host based USB driver creates EEM packets by prepending header to Ethernet Frame.
- Step 3: EEM packets are bundles into USB Packet up to bMaxpacket.
- Step 4: Host based USB driver sends USB Packet(s) (with payload) across the wire to the device. Device based USB driver accepts the USB Packet(s).
- Step 5: Device based USB driver unpacks USB Packet. Ethernet Frame is extracted from EEM packet. Ethernet frame is sent to device based Ethernet driver.
- Step 6: Ethernet Frame is reassembled from chunks and sends frame to device based Ethernet driver. Chunks that do not make up an existing frame are held until the rest of the frame arrives or an error condition.
- Step 7: Device based Ethernet driver accepts Ethernet frame.


## Appendix F: EEM Hardware Architecture Walkthrough

EEM simulates an Ethernet bus and removes the Ethernet hardware (refer to Figure 24 EEM ).




**Figure 24 EEM Walkthrough 1**

The simulated Ethernet bus is moved to the host to reduce firmware footprint (refer to Figure 25 EEM Walkthrough 2).



**Figure 25 EEM Walkthrough 2**

EEM (refer to Figure 26 EEM Walkthrough 3) pushes the simulated Ethernet bus to host based software.



**Figure 26 EEM Walkthrough 3**

Over the USB cable, encapsulated Ethernet frames flow starting with the destination MAC address and ending just before the frame checksum. (The frame checksum is not needed since USB is a reliable transport.) USB transfers could be used to encapsulate the frames or a header could precede the frame for fragmentation, etc.

EEM is implemented by writing a pseudo network adapter driver for both the host side and device side networking stack (which are probably different). The term pseudo is used because the network adapter driver does not control a traditional Ethernet chip but instead communicates with the USB host or device controller. This pseudo network adapter acts like a traditional Ethernet network adapter both sending and receiving packets but most importantly responding to key control and status operations.

A key control operation is the setting of the hardware unicast and multicast filters. Received frames which don't pass the filters ... broadcasts always pass ... are discarded. In the absence of software bridging, there should be no extraneous frames received and no frames should be discarded.

Key status operations are returning the permanent hardware address, connection status and statistics. The permanent hardware address is used by the network stack to fill in the source hardware address for frames to be sent. Connection status is used both for display and control of higher level protocols like DHCP. Statistics are for display and analysis.

## **Appendix G: Ethernet Bridging**

An EEM device may be a bridge and may be bridged but neither are required.

Communication between EEM devices (on the same USB bus) requires additional USB host implementation.